

514 MECKLEM LANE, ELLWOOD CITY, PENNSYLVANIA 16117 PHONE: 724-752-2000 FAX: 724-758-1558 www.hallindustries.com E-mail: service@hallindustries.com



## TB-980717 Equipment Manual Serves the DC-9, MD-80 and 717 Aircraft

# Use This Manual for 1. Operating Procedures 2. Maintenance Procedures 3. Tow Bar and Parts Ordering

### For ordering new Tow Bars or Renewable Parts

Please contact:

Hall Industries Equipment Division
514 Mecklem Lane
Ellwood City, PA 16117
Phone (724) 752-2000
FAX (724) 758-1558

"The Problem Solvers"

### TB-980717 EQUIPMENT MANUAL

SECTION I	<b>Description – Dimensions and Weights</b>
SECTION II	<b>Operating Procedures</b>
SECTION III	Maintenance Procedures
SECTION IV	Renewal Parts

#### SECTION I DESCRIPTION – DIMENSIONS AND WEIGHTS TB-980717 TOW BAR ASSEMBLY

Weight:	
Body	135#
Yoke	120#
Tow Bar, COMPLETE	255#
Length:	
Body with Tow Eye	124"
Head with Adapter	33"
Total Assembly	149"
Width:	
Yoke	43"
Height:	
Body	27"
Yoke	14"



HALL INDUSTRIES, Inc. PHONE: 724-752--2000 FAX: 724-758--1558

#### SECTION II OPERATING PROCEDURE TB-980717 TOW BAR ASSEMBLY

#### A. ATTACHING TOW BAR TO AIRCRAFT

The DC 9, MD 80 and the 717 can be towed forward or pushed aft on hard surfaces using a yoke-type Tow Bar. The Tow Bar attaches to the nose wheel axle by means of the nose pins on the yoke. When the tow bar yoke is lined up with the nose gear, the nose pins have to be manually locked in position on both sides of the nose gear by the operator.

#### **B. ATTACHING TOW BAR TO TOW TRACTOR**

Once the tow bar is securely attached to the nose gear, the tow tractor should be placed at the centerline of the Tow Bar. The operator must manually lift the tow bar to engage with the tow tractor and install the locking pin.

#### C. PUSHING THE AIRCRAFT

This must be done in accordance with the instructions in the Boeing or McDonnell Douglas Facility and Equipment Planning Manuals.

**CAUTION:** If at any time the shear bolt yields or breaks, carefully bring the aircraft to a stop. Before pushing or tow can be continued a new shear bolt must be inserted. Use only a Hall Industries shear bolt as follows, Part Number TB-980717-2.

#### D. DISCONNECTING TOW BAR FROM AIRCRAFT

Release the nose pins manually allowing the release of the yoke from the nose gear on the aircraft. Carefully move the tow bar and tow tractor clear of the aircraft.



HALL INDUSTRIES, Inc. PHONE: 724-752--2000 FAX: 724-758--1558

#### SECTION III MAINTENANCE PROCEDURES TB-980717 TOW BAR ASSEMBLY

- A. Inspect all Hardware.
- B. Check wheels and wheel carriage for bent, broken, or worn parts.
- C. Check for proper tire pressure. Correct pressure is 40 psi (maximum psi is 50).
- D. Lubricate wheels. There is a grease fitting on each wheel that requires lubrication each time you complete your scheduled maintenance, not to exceed 6 months.
- E. Lubricate the grease fittings (two sides) on the nose pin body each time you complete your scheduled maintenance, not to exceed 6 months.
- F. Check yoke assembly for operation of locking mechanism. Check the latch pin on the locking mechanism to insure it engages properly. There is an adjustable setscrew on the aluminum block locking mechanism. It is adjustable and should be checked to insure that the latch pin (when in down position) will stay locked. This setscrew is adjustable and should be adjusted as needed.
- G. When the latch pin is in the down position, it should secure the nose pin body in the appropriate position for the aircraft it is servicing. (Note: there are two separate positions}.
- H. Inspect yoke assembly for worn or damaged parts.
- I. Check tow eye on tow bar for damage and free rotation.
- J. Check tow bar main body tube for bending or cracking.
- K. Check shear pin and bushings for breakage and wear.
- L. Inspect for missing or illegible instruction plaques. Replace as required. See Attachment #1



HALL INDUSTRIES, Inc. PHONE: 724-752--2000 FAX: 724-758--1558

Rev. 07/16/01

#### SECTION IV RENEWAL PARTS TB-980717 TOW BAR ASSEMBLY TOW BAR TO SERVICE DC-9, MD-80, &17 AIRCRAFT

#### DWG TB-980717-11- YOKE ASSEMBLY

MK#	QTY / UNIT	DESCRIPTION	PART NUMBER
-	1	TB-980717 YOKE ASSEMBLY, COMPLETE	TB-980717-11
1R	1	RIGHT SIDE LATCH KIT	TB-7999-1-R
1L	1	LEFT SIDE LATCH KIT	TB-7999-1-L
1B	2	BUSHING, STRAIGHT	TB-9205-1B
2C	4	FLAT WASHER	TB-9205-2C
3	4	LOCK WASHER	ATR-302F
4	4	MICARTA BOLTS	1L04C0104ZPBG00
5	4	HEX NUT	HN04C0000ZPBG00
6	2	GREASE FITTING	TB-8649-2
7	1	WARNING TAG STEERING with RIVETS	TB-7999-TAG-A
8	1	WARNING PIN REMOVAL TAG with RIVETS	TB-7999-TAG-B
9	2	TWO POSITION PIN TAG with RIVETS	TB-7999-TAG-C
10	1	CAUTION WHEEL TAG with RIVETS	TB-7999-TAG-D
11A	1	YOKE ASSEMBLY W/ BUSHINGS (LESS ATTACHING Parts)	TB-980717-11A
12	2	INSERT, AXLE PIN	TB-9205-8
13	2	ROLL PIN	P443200445S0000
14	2	ROLL PIN HANDLE	P443601125S0000
15	2	NOSE PIN ASSEMBLY COMPLETE (INCL. 12,13,14,15-MKA)	TB-980717-15
15-MKA		NOSE PIN BODY	TB-980717-15-MKA
16	2	MICARTA SKID PADS	TB-980717-16
17	2	PLAQUE; LATCH PIN TAG with RIVETS	TB-980717-TAG



HALL INDUSTRIES, Inc. PHONE: 724-752--2000 FAX: 724-758--1558

1275

#### SECTION IV RENEWAL PARTS TB-980717 TOW BAR ASSEMBLY TOW BAR TO SERVICE DC-9, MD-80, &17 AIRCRAFT

MK # QTY / UNIT DESCRIPTION PART NUMBER					
12	1	TB-980717 TOW BAR BODY ASSEMBLY, COMPLETE	TB-980717-12		
1	1	PIVOT BOLT	TB-980717-1		
1A	2	BUSHING, FLANGED	TB-980717-1A		
1A2	2	BUSHING, FLANGED	TB-9205-1A		
1D	1	NYLOCK, HALF NUT	TB-980717-1D		
2	1	SHEAR BOLT	TB-980717-2		
1D2	1	STOVER LOCK NUT	TB-9205-1D		
3	1	CAPTURE BOLT	TB-9205-3		
3B	1	LOCKNUT	TB-9205-3B		
4	1	SWIVEL EYE BUSHING	TB-980717-12K		
5	1	TOW EYE RETAINER	TB-980717-12L		
6	4	BOLT, SWIVEL EYE BUSHING	H508C0032ZP0000		
7	4	NORD LOCK WASHER, SWIVEL EYE BUSHING	TB-8898-17-LW		
8	1	HOSE HANDLE	TB-980717-12M		
9	1	OVER TORQUE TAG with RIVETS	TB-8312-BA-TAG		
10	1	TOW EYE	TB-980717-12H		
12A	1	TOW BAR BODY W/ BUSHINGS (LESS ATTACHING PART			
13	1	WHEEL CARRIAGE ASSEMBLY	TB-980717-13		
		(INCL. 13A,13E,14,15,16,17,18)			
13A	1	WHEEL CARRIAGE WELDMENT	TB-980717-13A		
13E	2	U-BOLT	TB-980717-13E		
13⊑ 14	2 4	LOCK NUT	TB-8898-6		
14	4	NORD LOCK WASHER	TB-8649-4		
15	4	PNEUMATIC WHEEL	TB-8714-40		
10	2 4	FLAT WASHER	TB-8714-40 TB-8714-35		
17	4	COTTER PIN	TB-8714-35 TB-8714-28		
10	2	<b>OUTIER FIN</b>	10-0/14-20		



HALL INDUSTRIES, Inc. PHONE: 724-752--2000 FAX: 724-758--1558 Attachment # 1

PART NUMBER TB-7999-TAG A

PART NUMBER TB-7999-TAG B

WARNING

STEERING VALVE MUST BE <u>OPEN</u> PRIOR TO TOWING AIRCRAFT

WARNING- BEFORE LOCKPIN REMOVAL

<u>CLEAR</u> NOSEWHEEL AREA OF PERSONNEL AND TOWBAR

PART NUMBER TB-7999-TAG C

CAUTION TWO POSITION PINS

1 YELLOW BAND - WITHOUT SPRAY DEFLECTOR 2 YELLOW BANDS - WITH SPRAY DEFLECTOR

PART NUMBER TB-7999-TAG D

PART NUMBER TB-980717-TAG

PART NUMBER TB-8312-BA-TAG

CAUTION AVOID WHEEL DAMAGE RETRACT PINS FULLY WHEN REMOVING TOWBAR

WARNING: BEFORE TOWING THE LATCH PIN HANDLE NEEDS TO BE IN THE DOWN POSITION

> DO NOT OVER TORQUE BOLTS SHOULD ROTATE FREELY WITH WRENCH



HALL INDUSTRIES, Inc. PHONE: 724-752--2000 FAX: 724-758--1558

Rev. 07/16/01

МК	QTY	DESCRIPTION	PART NUMBER	BILL OF MATERIALS			
6	4	BOLT, SWIVEL EYE BUSHING	H508C0032ZP0000				PART NUMBER
7	4	NORDLOCK WASHER, SWIVEL EYE BUSHING	TB-8898-17-LW				
8	1	HOSE HANDLE	TB-980717-12M	12		TB-980717 TOW BAR BODY ASSEMBLY, COMPLETE	TB-980717-12
9	1	TAG OVER TORQUE W/ RIVETS	TB-8312-BA-TAG	1 1		PIVOT BOLT	TB-980717-1
10	1	TOW EYE	TB-980717-12H	1A	2	BUSHING, FLANGED	TB-980717-1A
12A	1	TOW BAR BODY WITH BUSHINGS (LESS ATTACHING PARTS)	TB-980717-12A	1D	1	NYLOCK HALF NUT	TB-980717-1D
13	1			2	1	SHEAR BOLT	TB-980717-2
		WHEEL CARRIAGE ASSEMBLY (INCL. 13A,13E,14,15,16,17,18)	TB-980717-13	1A2	2	BUSHING, FLANGED	TB-9205-1A
13A	1	WHEEL CARRIAGE WELDMENT	TB-980717-13A	1D2	1	STOVER LOCK NUT	TB-9205-1D
13E	2	U-BOLTS	TB-980717-13E	3	1	CAPTURE BOLT	TB-9205-3
14	4	LOCK NUT	TB-8898-6	3B	1	LOCK NUT	TB-9205-3B
15	4	NORDLOCK WASHER	TB-8649-4	4	1	SWIVEL EYE BUSHING	TB-980717-12K
16	2	PNEUMATIC WHEEL	TB-8714-40	5	1	TOW EYE RETAINER	TB-980717-12L
17	4	FLAT WASHER	TB-8714-35				
18	2	COTTER PIN	TB-8714-28				



